


MÜTER BMR 80



1,2	=restore II	P	7 = lifetest
3,4	=restore I	P	10 = push and adjust
5,6	=clean	P	17 = G1, cut off
7,8	=c-erase	P	18 = G2, cut off
9,10	=e-f-l-test	P	19 = focus - test
11,12=cut off		P	21 = repair short
13,14=repair short		P	25 = regeneration , red/bw
15,16=short test		P	26 = regeneration , green

MÜTER BMR 90

